

Sensor Dimmer CEM Settings

Normal Job Adjustments

Address Rack and Assign DMX

Press **Setup** Button
Press **2** Button
Press **>** Button until Display reads **Start Addr:**
Type **Address desired (usually 1)**(use 0-9 Buttons)
Press **Enter** Button
Press **Reset** Button

Direct Dimmer Control to Turn Dimmers on at the rack

This will override Console DMX control unless cleared

Press **Dimmer** Button

Type **Dimmer number** to turn on (use 0-9 Buttons)
Press **At** Button
Type **Dimmer Level** of 0-100 (use 0-9 Buttons)
Press **Enter** Button
Repeat Above 4 steps as needed

Press **Exit** Button to quit

Clearing Direct Dimmer Control

Press **Dimmer** Button

Type **Dimmer number** to release (use 0-9 Buttons)
Press **At** Button
Press **Clear** Button
Press **Enter** Button

When dimmer is cleared of direct control the display will read as **NOT SET**

Repeat Above 4 steps as needed

Press **Exit** Button to quit

Sensor Dimmer CEM Settings

Special Needs Adjustments

Dimmer Profile Values

Press	The Setup button
Press	The 1 button
Type	The Dimmer Number to adjust (use 0-9 Buttons)
Press	The > button to advance between items
Press	The enter button to select an item to edit
Press	The up and down arrows to change settings

Curve value should be **Mod Square**

Scale value should be **118**

For normal operation

Mode and **Threshold** values should be **Normal**

For special non-dimming operation

Mode value should be **Non-dim** and **Threshold** value should be **always on**

Press	The enter button accept the change
Repeat	Above steps as needed
Press	The Exit button to end

Generate Defaults


Press & hold the **Dimmer** button.
Whilst still holding the button
Press & release the **Reset** button
Release the **Dimmer** button when screen resets

Press the **Dimmer** button
Repeat the above step until the **password received** message appears
Press the **Enter** button
Press the **4** button
Press the **1** button
Press the **Enter** button
The **overwrite configuration?** Message will appear
Press & hold the **^** button until **YES** appears
Press & hold the **Enter** button until Initialization begins

Press the **>** button to advance between the following items
Press the **enter** button to select an item to edit
Press the **up and down arrow** buttons to change settings

The **# Racks** value should be **1**
The **Rack type** value should be **SP24** for Touring Rack or
The **Rack type** value should be **SR6** for 12 Pack
The **CEM** value should be **120v**
The **Setup Module** value should be **D20**
Press the **enter** button to accept the change
Press the **Exit** button to end more initialization will occur
The display will read **etclink 1**
Press the **enter** button

Sensor Dimmer CEM+ Settings Normal Job Adjustments



Address Rack

Press **Accept**
Press **Plus or Minus** until address is shown
Press **Accept**

Direct Dimmer Control to turn on Dimmers at the Rack

To Select a Single Dimmer

Press **Set Levels**
Press **Accept**
Press **Plus or Minus** to get **Dimmer**
Press **Accept**
Press **Accept**
Press **Plus or Minus** to set level
Press **Accept**

To Select a Group of Dimmers

Press **Set Levels**
Press **Accept**
Press **Plus or Minus** to get starting dimmer
Press **Accept**
Press **Plus or Minus** to get ending dimmer
Press **Accept**
Press **Plus or Minus** to set level
Press **Accept**

To Release

Press **Set Levels**
Press **Accept**
Press **Plus or Minus** to get to the dimmer you want to release
Press **Accept**
Press **Accept**
Press **Plus or Minus** until screen reads **Release**
Press **Accept**

Frost | Productions

Sensor Dimmer CEM Settings Special Needs Adjustments

To Get to Advanced Features

Press **Accept**
Press **Minus** Until **Configure**
Press **Accept**
Set Password 3333
Press **Accept**
Press **Plus** until **Full Feature**
Press **Accept**
Press **Accept Voltage [120]**
Press **Accept Phase Balance [Straight 3-Phase]**
Press **Accept Rack Type**, SP-6=12 rack, SP12=24 rack, **SP24=48** rack(our road racks are SP24)
Press **Accept Module Type [D20]**
Press **Accept Dimmer Double [Off]**
Press **Accept DMX Start [1]**
Press **Accept**
Save Changes
Press **Plus** to **Yes**
Press **Accept** (rack will reset in advanced mode)

After the Rack Restarts Follow these steps to set up the Dimmers

To Set Dimmer Curve

Press **Plus** to **Dimmer**
Press **Accept**
Press **Plus** to **Setup Dimmer**
Press **Accept**
Press **Plus** to **Set Curve**
Press **Accept**
Set Dimmer Range
Press **Accept**
Curve should be Set to **Mod-Square**

To Set Dimmer Mode

Press **Plus** to **Dimmer**
Press **Accept**
Press **Plus** to **Firing Mode**
Press **Accept**
Set Dimmer Range
Press **Accept**
Normal Operation = **Normal**
Non-dim Operation= **Always On**
Press **Accept**